


# Edifier

R18

---

Multimedia Speaker



## User's Manual

Edifier Enterprises Canada Inc.

---

Made in China

## *Congratulations on your Edifier Purchase !*

Very thanks for choosing Edifier multimedia speaker, it can provide good sound for multimedia Computer and home theater. Before operating the system, please read this manual thoroughly and retain it for future reference.

### Notice

**Edifier** and Edifier logo are owned by Edifier Hi-Tech Group and may be registered. And other brand names and trademarks are the property of their owners. Edifier assumes no responsibility for any errors that may appear in this manual. Information contained herein is subject to change without notice.

## SAFETY INSTRUCTIONS

- Read these instructions.
- Keep these instructions.
- Heed all warnings.
- Follow all instructions.
- Install in accordance with the manufacturer's Instructions.
- Do not use the speakers near water, and do not immerse them in any liquid or pour any liquid on them.
- Do not block the openings in the speaker cabinets, never push objects into speaker vents or slots because of fire or electric shock hazards, and provide sufficient space around the speakers for proper ventilation.
- The apparatus shall not be exposed to dripping or splashing and that no objects filled with liquids, such as vases, shall be placed on the apparatus.
- Do not install near any heat sources such as radiators, heat registers, stoves, or other apparatus (including amplifiers) that produce heat.
- Do not defeat the safety purpose of the polarized plug. A polarized plug has two blades with one wider than the other. The wide blade is provided for your safety. If the provided plug does not fit into your outlet, consult an electrician for replacement of the obsolete outlet.
- Protect the power cord from being walked on or pinched particularly at plugs, convenience receptacles, and the point where they exit from the apparatus.
- For added protection during lightning storms, unplug the speakers from the electrical outlet and turn off the computer.
- Unplug this apparatus when unused for long periods of time.
- Water and moisture ---- Do not use the speakers near water, and do not immerse them in any liquid or pour any liquid on them.
- Heat---- Place the speakers away from all heat sources.
- Ventilation ---- Do not block the openings in the speaker cabinets, never push objects into speaker vents or slots because of fire or electric shock hazards, and provide sufficient space around the speakers for proper ventilation.
- Location ---- Place the speakers in a stable location so they will not fall causing damage to the speakers or bodily harm.
- Cleaning ---- Unplug the speakers from the computer and from the electrical outlet before cleaning them with a damp cloth.
- Lightning ---- For added protection during lightning storms, unplug the speakers from the electrical outlet and turn off the computer.
- Servicing is required when the apparatus has been damaged in any way, such as power-supply cord or plug is damaged, liquid has been spilled or objects have fallen into the apparatus, the apparatus has been exposed to rain or moisture, does not operate normally, or has been dropped. Refer all servicing to qualified service personnel.
- Please adjust the audio to proper volume to avoid damaging your health and the system.

### **WARNING:**

**TO REDUCE THE RISK OF ELECTRIC SHOCK, DO NOT EXPOSE THIS APPARATUS TO RAIN OR MOISTURE.**

## PACKAGE




### Packing list:

- 1、 1 x Main speaker
- 2、 1 x Second speaker
- 3、 1 x Operating manual

## OVERVIEW



### Overview:




- |                   |                    |
|-------------------|--------------------|
| 1、 Second speaker | 2、 Main speaker    |
| 3、 Power switch   | 4、 Power indicator |
| 5、 Headphone      | 6、 Volume          |
| 7、 3.5mm Line-in  | 8、 Power cord      |
| 9、 Power cord     |                    |

## CONNECTING SYSTEM



Connecting:



To Sound field(such as SOUND CARD, DVD, etc)

### 1: Connect Sound Field:

Connect the Line-in stereo plug on the main speaker to the main speaker to the sound field, such as Sound card.

### 2: Playing:

Connect the power plug to the AC outlet, then adjust the volume and the super bass to a comfortable level, turn on power switch, you can play.

## SPECIFICATION



Specifications:

Power Output: RMS 2WX2

Input Impedance: 10K Ohm

Input Sensitive: 250mV

Speaker Unit: Paper Voicecoil , 4Ohm

Dimension: 85(W)x166(H)x125(D)mm

Total Weight: About 1.8kg